

**SWITCHBLADE® Windshields with Quick Release Mount Kit**

APPLICATION GUIDE	Years	MOUNT KIT	2-UP	CHOPPED		SHORTY		DEFLECTOR		CHROME LOWERS	HOLDSTER
				CLEAR	TINT	CLEAR	TINT	CLEAR	TINT		
<b>HARLEY-DAVIDSON</b>											
<b>XL MODELS with 39mm Fork Tubes. (NOTE: SOME 1987 MODELS MAY HAVE 39mm FORK TUBES. CHECK FORK DIAMETER BEFORE ORDERING)</b>											
XL/XLH/XLCH Sportster	1988-93	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
XL1200L/XL883L Sportster Low	2005-2009	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
XL1200C/XL883C Sportster Custom	2004-09	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
XL1200C/XL883C Sportster Custom	1996-03	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
XL1200S Sportster Sport	1996-03	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
XL1200R/XL883R Sportster	2001-09	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
XL1200N Nightster	2008-09	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
XL1200/XL883 Sportster	2004-2009	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
XLH1200/XLH883 Sportster	1994-03	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
XLH1200/XLH883 Sportster	1988-93	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
<b>FX MODELS Narrow Glide with 39mm Fork Tubes (NOTE: SOME 1987 MODELS MAY HAVE 39mm FORK TUBES. CHECK FORK DIAMETER BEFORE ORDERING)</b>											
FXD/FXDL/FXDX/FXDC (Dyna Series)	1993-05	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
FXLR Low Rider Custom	1988-94	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
FXR/FXRS Low Rider	1988-94	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
FXDS Convertible Dyna Low Rider	1994-99	Kit-Q141	N21117	N21417	N21418	N21717	N21718	N21917	N21918	N76605	N/A
<b>FX MODELS Narrow Glide with 49mm Fork Tubes</b>											
FXDI Super Glide	2006-09	Kit-Q143	N21131	N21431	N21432	N21731	N21732	TBA	TBA	TBD	N/A
FXDCI Super Glide Custom	2006-09	Kit-Q143	N21131	N21431	N21432	N21731	N21732	TBA	TBA	TBD	N/A
FXDI35 35th Anniversary Super Glide	2006	Kit-Q143	N21131	N21431	N21432	N21731	N21732	TBA	TBA	TBD	N1321
FXDBI Street Bob	2006-09	Kit-Q143	N21131	N21431	N21432	N21731	N21732	TBA	TBA	TBD	N1321
FDXF Fat Bob	2008	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
FXDLI Low Rider	2006-09	Kit-Q143	N21131	N21431	N21432	N21731	N21732	TBA	TBA	TBD	N1321
<b>FX MODELS Wide Glide with 49mm Fork Tubes</b>											
FXDWGI Dyna Wide Glide	2006-09	Kit-Q143	N21133	N21433	N21434	N21733	N21734	TBA	TBA	N76605	N1321
<b>FX MODELS Wide Glide with 41mm Fork Tubes</b>											
FXDWG Dyna Wide Glide	1993-05	Kit-Q142	N21119	N21419	N21420	N21719	N21720	N21919	N21920	N76605	N1321
FXWG Wide Glide	1980-85	Kit-Q142	N21119	N21419	N21420	N21719	N21720	N21919	N21920	N76605	N1321
FXDG Disc Glide	1983	Kit-Q142	N21119	N21419	N21420	N21719	N21720	N21919	N21920	N76605	N1321
<b>FX MODELS Softail</b>											
FXSTD/FXSTDI Softail Deuce	2000-07	Kit-Q142	N21119	N21419	N21420	N21719	N21720	N21919	N21920	N76605	N1321
FXSTB/FXSTBI Softail Night Train	1999-09	Kit-Q142	N21119	N21419	N21420	N21719	N21720	N21919	N21920	NO FIT	N1321
FXST/FXSTI Softail Standard	84-90,99-07	Kit-Q142	N21119	N21419	N21420	N21719	N21720	N21919	N21920	N76605	N1321
FXSTC Softail Custom	87-99,07-09	Kit-Q142	N21119	N21419	N21420	N21719	N21720	N21919	N21920	N76605	N1321
<b>FL MODELS Softail (With No H-D Light Bar Installed)</b>											
FLSTF Fat Boy	1990-09	Kit-Q341	N21127	N21427	N21428	N21727	N21728	N21927	N21928	N76606	N1321
FLSTC Heritage Softail Classic	1987-09	Kit-Q341	N21127	N21427	N21428	N21727	N21728	N21927	N21928	N76606	N1321
FLSTN/H Heritage Softail Special	1994-96	Kit-Q341	N21127	N21427	N21428	N21727	N21728	N21927	N21928	N76606	N1321
FLSTN Heritage Softail Nostalgia	1993	Kit-Q341	N21127	N21427	N21428	N21727	N21728	N21927	N21928	N76606	N1321
FLST Heritage Softail	1986-90	Kit-Q341	N21127	N21427	N21428	N21727	N21728	N21927	N21928	N76606	N1321
<b>FL MODELS Softail (With H-D Light Bar Installed)</b>											
FLSTF Fat Boy	1990-09	Kit-Q342	N21127	N21427	N21428	N21727	N21728	N21927	N21928	N76606	N1321
FLSTC Heritage Softail Classic	1987-09	Kit-Q342	N21127	N21427	N21428	N21727	N21728	N21927	N21928	N76606	N1321
FLSTN(H) Heritage Softail Special	1994-96	Kit-Q342	N21127	N21427	N21428	N21727	N21728	N21927	N21928	N76606	N1321
FLSTN Heritage Softail Nostalgia	1993	Kit-Q342	N21127	N21427	N21428	N21727	N21728	N21927	N21928	N76606	N1321
FLST Heritage Softail	2006	Kit-Q342	N21127	N21427	N21428	N21727	N21728	N21927	N21928	N76606	N1321
FLST Heritage Softail	1986-90	Kit-Q342	N21127	N21427	N21428	N21727	N21728	N21927	N21928	N76606	N1321
<b>FLH MODELS Road King (With or without H-D Light Bar installed)</b>											
FLHR/I Road King	1994-09	Kit-Q343	N21139	N21439	N21440	N21739	N21740	N/A	N/A	N/A	N1321
FLHRC/I Road King Classic	1996-09	Kit-Q343	N21139	N21439	N21440	N21739	N21740	N/A	N/A	N/A	N1321
FLHRS/I Road King Custom	2004-07	Kit-Q343	N21139	N21439	N21440	N21739	N21740	N/A	N/A	N/A	N1321

<b>HONDA</b>											
NRX1800 RUNE	2004-05	KIT-Q103	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N/A	N/A
VTX1800R/S Retro	2002-03	KIT-Q103	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76607	N1321
VTX1800R/S Retro (Spec 1 Only)	2004-07	KIT-Q103	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76607	N1321
VTX1800R/S Retro (Spec 2 and Spec 3 Only)	2004-07	KIT-Q105	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76601	N1321
VTX1800N (Spec 1 Only)	2004-08	KIT-Q103	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76607	N1321
VTX1800N (Spec 2 and Spec 3 Only)	2004-08	KIT-Q105	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76601	N1321
VTX1800F (Spec 1 Only)	2005-08	KIT-Q103	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76607	N1321
VTX1800F (Spec 2 and Spec 3 Only)	2005-08	KIT-Q105	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76601	N1321
VTX1800C	2002-04	KIT-Q103	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76607	N1321
VTX1800C (Spec 1 Only)	2005-07	KIT-Q103	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76607	N1321
VTX1800C (Spec 2 and Spec 3 Only)	2005-07	KIT-Q105	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76601	N1321
VTX1800T (Spec 1 Only)	2007-08	KIT-Q103	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76607	N1321
VTX1800T (Spec 2 Only)	2007-08	KIT-Q105	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76601	N1321
GL1500C Valkyrie	1997-03	KIT-Q103	N21125	N21425	N21426	N21725	N21726	N/A	N/A	N/A	N1321
<b>HONDA (cont.)</b>											
VTX1300R/S	2003-09	KIT-Q203	N21111	N21411	N21412	N21711	N21712	N21907	N21908	N76604	N1321
VTX1300C	2004-09	KIT-Q102	N21105	N21405	N21406	N21705	N21706	N21905	N21906	N76601(14)	N1321
VT1100C2 Shadow A.C.E.	1995-99	KIT-Q102	N21101	N21401	N21402	N21701	N21702	N21901	N21902	N76601	N1321
VT1100C2 Shadow Sabre	2000-07	KIT-Q203	N21103	N21403	N21404	N21703	N21704	N21903	N21904	N76601	N1321
VT1100 Shadow Spirit	1997-07	KIT-Q102	N21101	N21401	N21402	N21701	N21702	N21901	N21902	N76601(14)	N1321
VT1100 Shadow	1995-97	KIT-Q102	N21101	N21401	N21402	N21701	N21702	N21901	N21902	N76601	N1321
VT1100 Shadow	1987-94	KIT-Q102	N21101	N21401	N21402	N21701	N21702	N21901	N21902	N76601	N1321
VT750C Shadow A.C.E	1997-00	KIT-Q102	N21101	N21401	N21402	N21701	N21702	N21901	N21902	N76601	N1321
VT750C2 Shadow Spirit	2007-09	KIT-Q102	N21101	N21401	N21402	N21701	N21702	N21901	N21902	N76601(4)	N1321
VT750DC Shadow Spirit/Black Widow	2001-07	KIT-Q102	N21101	N21401	N21402	N21701	N21702	N21901	N21902	N/A	N1321
VT750 Shadow Aero	2004-09	KIT-Q203	N21103	N21403	N21404	N21703	N21704	N21903	N21904	N76601	N1321
VT750CD Shadow A.C.E Deluxe	1997-03	KIT-Q203	N21103	N21403	N21404	N21703	N21704	N21903	N21904	N76601	N1321
<b>KAWASAKI</b>											
VN2000	2004-09	KIT-Q302	N21115	N21415	N21416	N21715	N21716	N21915	N21916	N76603	N1321
VN1600D/G Vulcan Nomad	2005-08	KIT-Q301	N21113	N21413	N21414	N21713	N21714	N21913	N21914	N76602	N1321
VN1600A Vulcan Classic	2003-08	KIT-Q301	N21113	N21413	N21414	N21713	N21714	N21913	N21914	N76602	N1321
VN900C Vulcan 900 Custom	2007-09	KIT-Q102	N21135	N21435	N21436	N21735	N21736	N21909	N21910	N/A	N1321
VN 800A Vulcan	1995-05	KIT-Q102	N21109	N21409	N21410	N21709	N21710	N21909	N21910	N76601	N1321
<b>SUZUKI</b>											
C109R Boulevard	2008-09	TBA	TBA	TBA	TBA	TBA	TBA	TBA	TBA	TBA	TBA
C50 Boulevard	2005-09	KIT-Q202	N21123	N21423	N21424	N21723	N21724	N21905	N21906	N76601	N1321
VL800 Intruder Volusia	2001-04	KIT-Q202	N21123	N21423	N21424	N21723	N21724	N21905	N21906	N76601	N1321
M50 Boulevard	2005-09	KIT-Q103	N21105	N21405	N21406	N21705	N21706	N21905	N21906	N/A	N1321
<b>VICTORY</b>											
Kingpin	2004-09	KIT-Q103	N21125	N21425	N21426	N21725	N21726	N/A	N/A	N/A	N/A
Kingpin Low	2009	KIT-Q103	N21125	N21425	N21426	N21725	N21726	N/A	N/A	N/A	N/A
Kingpin 8-ball	2008-09	KIT-Q103	N21125	N21425	N21426	N21725	N21726	N/A	N/A	N/A	N/A
Kingpin "Ness Edition"	2005	KIT-Q103	N21125	N21425	N21426	N21725	N21726	N/A	N/A	N/A	N/A
Hammer/Hammer S	2005-09	KIT-Q103	N21125	N21425	N21426	N21725	N21726	N/A	N/A	N/A	N/A
<b>YAMAHA</b>											
XV19C Raider/Raider S	2008-09	KIT-Q131	N21105	N21405	N21406	N21705	N21706	N21905	N21906	N/A	N1321
XV17A Road Star / Wild Star	2004-09	KIT-Q205	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76601	N1321
XV1600A Road Star / Wild Star	1999-03	KIT-Q205	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76601	N1321
XVZ1300A Royal Star	1996-00	KIT-Q205	N21107	N21407	N21408	N21707	N21708	N21907	N21908	N76601	N1321
XVS1300A V-Star 1300	2007-09	KIT-Q204	N21137	N21437	N21438	N21737	N21738	N21905	N21906	N76604	N1321
XVS1100A V-Star/DragStar Classic	1999-09	KIT-Q204	N21105	N21405	N21406	N21705	N21706	N21905	N21906	N76601	N1321
XVS1100 V-Star/DragStar Custom	1999-09	KIT-Q102	N21109	N21409	N21410	N21709	N21710	N21909	N21910	N/A	N1321
XVS650 V-Star/DragStar Custom	1997-09	KIT-Q102	N21109	N21409	N21410	N21709	N21710	N21909	N21910	N/A	N1321
XVS650A V-Star/DragStar Classic	1998-09	KIT-Q204	N21105	N21405	N21406	N21705	N21706	N21905	N21906	N76601	N1321